



REMOTE PROGRAMMING REQUIREMENTS

WHEN PROGRAMMING, ETHERNET CABLE CONNECTION AND BATTERY MAINTAINER ARE REQUIRED

LOGGING IN

Go to <https://customers.elitekauto.com>

Use the login provided in welcome email

If you forgot your password, click
Forgot Password

Can't find welcome email or your username?
Email us and we will gladly send it to you.
remote@elitekauto.com



IT REQUIREMENTS

- If using Wi-Fi your network must be running the 2.4ghz band.
- If using Ethernet connection, you must use high quality CAT5-E or CAT6 cable.
- If you're unsure if you may have ports blocked, you can use this link to check your port settings <https://portscan.obd.help:46329/>





STEP 1.

Connecting the Elitek Remote Scanning Device to your wifi network:

- a. Connect the device to the OBD Port of any vehicle that is in range of your Wi-Fi. The green LED at the top right of the ethernet port on the device will start slowly flashing.
- b. Using a phone or tablet, open your Wi-Fi settings and select the Connector XXXXX (For reference the connector number is on the back of the device).
- c. Open a web browser and navigate to connector.help. Select your Wi-Fi network and enter your Wi-Fi password.
- d. Wait for about 1 minute for both the green and orange LED to light steadily. The device is then connected to your shop Wi-Fi. If not, reset the Elitek Remote Scanning Device (see bottom left section).

To link or reset the Elitek Remote Scanning Device to another network:



- Connect the 16-pin OBD connector of the device to the OBD port of a vehicle.
- Use the supplied reset pin or a paperclip and press the reset switch for about 10 seconds and release it.
- The orange LED is constantly on and the green LED is flashing slowly: the Elitek Scanning Device is ready to connect to the network.
- From here, go back to step 2b.

STEP 2.

Prepare for use.

- Go to elitek.obd.help via the browser of your PC / laptop, tablet or smartphone or scan the QR code and fill in the login details you received by email.



FEDERAL COMMUNICATIONS COMMISSION (FCC) INFORMATION

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. No changes shall be made to the equipment without the manufacturer's permission as this may void the user's authority to operate the equipment.

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. This device must be installed and operated with a minimum distance of 20 cm between the radiator and your body.

INDUSTRY CANADA (IC) INFORMATION

This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

IMPORTANT NOTE:

ISED Radiation Exposure Statement: This equipment complies with ISED RSS 102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum separation distance of 20cm between the device and all persons.

Cet équipement est conforme aux limites d'exposition au rayonnement ISED RSS 102 définies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec une distance de séparation minimale de 20 cm entre l'appareil et toutes les personnes.



FOR MORE INFORMATION, PLEASE CONTACT US AT:

888-8-ELITEK | (888) 835-4835

REMOTE@ELITEKAUTO.COM

ELITEKAUTO.COM

SCAN HERE

